

# BRADCO Service Bulletin



*The Power of Combined Excellence*

There has been an update to the BRADCO Skid Steer Loader Swing Hoe. Due to reports of external leaking of the valves on the swing hoe the hardware connecting the valves has been changed to four .31" UNC X 4.75" Socket Head Capscrews, eight flat washers and four deformed lock nuts. **NOTE: When replacing your existing .25" hardware check o'rings between valves for damage and replace if necessary.**

See the diagram below to verify hose routings to the bucket cylinder and to the bulkhead fittings going to the swing cylinder. These hoses are not interchangeable due to the hose length. If these hoses are switched around on your unit, please reroute as shown to prevent hose damage and to achieve the desired operating function of swing left and dump.

**NOTE: ALL REPAIR ITEMS CAN BE ORDERED FROM BRADCO PARTS DEPARTMENT. CONTACT OUR TECHNICAL SERVICE TEAM IF YOU HAVE A QUESTION CONCERNING POSSIBLE WARRANTY.**

